

ROCKER TOE MODIFICATION

You may find that a rolled toe modification or shoes that already have some enhancement for breakover don't provide enough improvement for the foot movement. A "rocker toe" modification may be a better solution for moving the point of breakover back further, without having to move the entire shoe back. The steps in the modification of this Kerckhaert Standard Extra show the simple process to create the rocker toe. Of course you have to consider how to adjust the toe of the foot to accommodate the rocker- usually an adjustment you can do with the rasp, but important to match to your shoe modification.



PHOTO 1: Place shoe on edge of anvil at desired location for breakover point.

PHOTOS 2, 3 AND 4: Set corners of rocker.

PHOTOS 5, 6 AND 7: Now finalize rocker toe section and angle.

PHOTO 8: You can see distinct line where rocker toe break over point is set.

PHOTO 9: Flatten shoe.

PHOTOS 10 AND 11: Rocker toe is set and easy to see in these images.



For the name of a farrierproducts™ dealer near you, visit www.farrierproducts.com or call 1-800-468-2879. Find the best shoes for all disciplines on FPD's Field Guide for Farriers at www.farrierproducts.com/fieldguide.

Connect with FPD
and Join the Conversation

